Potentiometer Input Alarm Trips, Factory Ranged, Isolated APD 1800, APD 1820, APD 1830 Input: **100** Ω to 1 M Ω Potentiometers APD 1830 discontinued Output: Two 8 Amp SPDT Relays Accepts Most Full-Range Potentiometers Removable Plugs Removable Plugs for Faster Installation Two 8 Amp SPDT Input LoopTracker® and Alarm Status LEDs Alarm Relays Full 1200 V Isolation Alarm Test, Optional Reset Button Alarm Test Applications Function to Band Position Alarm ilam lite Tank Level Alarm An Input LoopTracker Position Over, Under, Out-of-Range Alarm LED An **Potentiometer Input Ranges** . Full travel of the potentiometer is required Alarm Status LED 3 wire connection required 1 VDC excitation provided to potentiometer APD 1830 Minimum range: 0-100 Ω Adjustable 0-1 MΩ Maximum range: APD 1820 Deadband and Input Impedance Setpoint APD 1800 $1 M\Omega$ minimum 9 10 11 Isolation Any Full-Range 1200 V isolation: power to input 15 16 Potentiometer 600 VAC_P or 600 VDC common mode protection Input LoopTracker Variable brightness LED indicates input loop level and status APD 1800 Relay Output Universal Single setpoint dual SPDT Form C contact sets Power Standard: HI alarm, non-latching, normal acting Options: LO alarm, latching, reverse acting APD 1820 Relay Output Description 2 independent setpoint SPDT Form C contact sets The APD 1800, 1820, and 1830 will accept any potentiometer Standard: HI/LO alarm, non-latching, normal acting File E145968 with a value of 0-100 Ω through 0-1 M Ω without recalibration Options: LO/LO, HI/HI, LO/HI alarms, latching, reverse acting 85-265 VAC, 60-300 VDC and without affecting accuracy. APD 1830 Relay Output model only Consult factory for offsets and/or input ranges other than 0 to 2 independent setpoint SPDT Form C contact sets 100% of the potentiometer range. Standard: Band alarm (both alarms trip if outside LO and HI Front-accessible potentiometers are used to adjust each alarm IEÉTIME trip points), non-latching, normal acting setpoint and deadband. Options: Inverse band alarm, latching, reverse acting ARRANT MADE IN USA LoopTracker and Alarm Status LEDs **Relay Contact Ratings** API exclusive features include a LoopTracker LED that varies in 8 A max @ 240 VAC resistive load intensity with changes in the process input signal An RC snubber is recommended for inductive loads A red/green bi-color alarm status LED (two on the APD 1820 AC inductive load AC resistive **Quick Link** ree Facto $(\cos\,\varphi=0.4)$ and 1830) visually indicate alarm status. These LEDs provide a load I/O Setup api-usa.com/1800 quick visual picture of your process at all times. E 5 **Output Test / Unlatch** Switching Current Dimensions API's exclusive Output Test button can be used to verify the DC inductive load (L/R = 7 ms)0.89" W x 4.62" H x 4.81" D (22.5 x 117 x 122 mm) alarm and system operation and also provides the additional function of unlatching the alarm when the latching option has Height includes connectors DC resistive load been ordered. This feature can be remotely operated. Power 85-265 VAC. 50/60 Hz or 60-300 VDC. 2 W maximum The output test button greatly aids in saving time during initial 30 50 100 300 500 D versions: 9-30 VDC or 10-32 VAC 50/60 Hz, 2 W maximum startup and/or troubleshooting. Switching Voltage (V) Setpoint 12 turn potentiometer adjustable from 0 to 100% of span Model Input Standard Alarm Configuration Power APD 1800 85-265 VAC or 60-300 VDC Deadband Single setpoint dual SPDT relays HI alarm, non-latching, normal acting APD 1800 D 9-30 VDC or 10-32 VAC 12 turn potentiometer adjustable from 1 to 100% of span Any full-range potentiom-APD 1820 2 setpoints, 2 SPDT relays 85-265 VAC or 60-300 VDC **Response Time** eter from 0-100 Ohm to APD 1820 D HI/LO alarms, non-latching, normal acting 9-30 VDC or 10-32 VAC 70 milliseconds typical 0-1 Mega Ohm APD 1830 2 setpoints, 2 SPDT relays 85-265 VAC or 60-300 VDC **Output Test/Reset Button** APD 1830 D Band alarm, non-latching, normal acting 9-30 VDC or 10-32 VAC Front button or external contact closure toggles relays to opposite state when pressed. Resets relay if latching relay option is ordered Alarm Options-add to end of model number HT Latching alarm with push button reset APD 1800 with L0 trip. Alarm trips on decreasing signal. **Ambient Temperature Range and Stability** Т HP Latching alarm with power-off reset. Module power -10°C to +60°C operating ambient HH APD 1820 with HI/HI trip. Alarms trip at their respective must be turned off to reset alarms Better than 1% of span over operating temperature range trip points on increasing signal. Reverse-acting alarms. Relay coils energized in an alarm R Better than 0.02% of span per °C APD 1820 with LO/LO trip. Alarms trip at their respective condition. No alarm condition with module power off. LL Housing and Connectors trip points on decreasing signal. U Conformal coating for moisture resistance IP 40, requires installation in panel or enclosure 1 H APD 1820 with LO/HI trip. Alarm 1 trips on decreasing Spare Connector For use in Pollution Degree 2 Environment signal. Alarm 2 trips on increasing signal. API BP4 4 terminal plug, black Mount vertically to a 35 mm DIN rail IB APD 1830 with Inverse Band alarm. Both alarms trip if Four 4-terminal removable connectors, 14 AWG max wire size signal is between LO and HI trip points. © 03-17

BSOLUTE **PROCESS i**NSTRUMENTS, Inc.

api-usa.com

Installation and Setup

Precautions

WARNING! All wiring must be performed by a qualified electrician or instrumentation engineer. See diagram for terminal designations and wiring examples. Consult factory for assistance.

WARNING! Avoid shock hazards! Turn signal input, output, and power off before connecting or disconnecting wiring, or removing or installing module.

Précautions

ATTENTION! Tout le câblage doit être effectué par un électricien ou ingénieur en instrumentation qualifié. Voir le diagramme pour désignations des bornes et des exemples de câblage. Consulter l'usine pour assistance.

ATTENTION! Éviter les risques de choc! Fermez le signal d'entrée, le signal de sortie et l'alimentation électrique avant de connecter ou de déconnecter le câblage, ou de retirer ou d'installer le module.

Signal Input Terminals

The potentiometer must be connected to all three signal input terminals as shown in the wiring diagrams. 0-100% of the potentiometer range must be used unless a special range was ordered. A stable 1 VDC source is used to excite the potentiometer.

Alarm Types

Note that the deadband is symmetrical about the setpoint; relay trip and reset points will both change if either the setpoint or deadband are changed.

High Alarm (default, H, or HH): The alarm relay changes state when the input exceeds the deadband trip point. The relay resets when the input drops below the deadband reset point. For a high alarm, the trip point is above the reset point.

Low Alarm (L or LL): The alarm relay changes state when the input goes below the deadband trip point. The relay resets when the input exceeds the deadband reset point. For a low alarm the trip point is below the reset point.

Band Alarm: Both alarm relays change state when the input is outside either deadband trip point.

Inverse Band Alarm (IB): The alarm relay changes state when the input is inside either deadband trip point.

HT: Latching alarm with push button reset

HP: Latching alarm with power-off reset. Module power must be turned off to reset alarms

R: Reverse-acting alarms. Relay coils energized in an alarm condition. No alarm condition with module power off.

Relay Output Terminals

See wiring diagrams below right for connections. APD modules do not provide power to the relay contacts. Inductive loads (motors, solenoids, contactors, etc.) will greatly shorten relay contact life unless an appropriate RC snubber is installed.

The APD 1800 operates two sets of relays in unison with a single setpoint. The dual SPDT contact sets are in a Form C configuration.

The APD 1820 operates two sets of relays independently, each with its own setpoint. The dual SPDT contact sets are in a Form C configuration.

The APD 1830 operates two sets of relays, each with its own setpoint in a band alarm configuration. The dual SPDT contact sets are in a Form C configuration.

Module Power Terminals

Check model/serial number label for module operating voltage to make sure it matches available power.

When using DC power, either polarity is acceptable, but for consistency with similar API products, positive (+) can be wired to terminal 13 and negative (-) can be wired to terminal 16.

Mounting to a DIN Rail

Install module vertically on a 35 mm DIN rail in a protective enclosure away from heat sources. Do not block air flow.

1. Tilt front of module downward and position against DIN rail.

- 2. Clip lower mount to bottom edge of DIN rail.
- 3. Push front of module upward until upper mount snaps into place.

Removal

- $1. \ \ \text{Push up on the bottom back of the module.}$
- Tilt front of module downward to release upper mount from top edge of DIN rail
- 3. The module can now be removed from the DIN rail.

Setup and Calibration

The input can accept any full-range potentiometer and does not require adjustment.

Relay operation is factory configured. See model/serial number label for relay configurations.

The Setpoint potentiometer allows the operator to adjust the level at which the alarm is activated. This control is adjustable from 0 to 100% of the input range.

The Deadband potentiometer allows the alarm trip and reset window to be adjusted symmetrically about the setpoint from 1 to 100% of the span. This allows the operator to fine tune the point at which the alarm trips and resets. The deadband is typically used to prevent chattering of the relays or false trips when the process signal is unstable or changes rapidly.

To calibrate the alarm section, set the deadband control to the minimum (counterclockwise). The deadband will be 1.0% of input span in this case.

Set the signal source to a reference that represents the desired trip point.

Adjust the setpoint control to the point at which the relay changes state from a non-alarm to an alarm condition.

If a larger amount of deadband is desired turn the deadband potentiometer clockwise. The deadband is symmetrical about the setpoint; both transition points will change as deadband is increased.

Relay set and reset points will both change if the setpoint or deadband are changed. Alternately set the setpoint and deadband until the desired trip and rest points are set.

Output Test Function

When the front test button is depressed it will drive the relays to their opposite state. A customer-supplied switch connected to terminal 4 and 8 can also be used to toggle the relays. When released, the relays will return to their prior states.

This can be used as a diagnostic aid during initial start-up or troubleshooting, or as a manual over-ride function. The Test button also resets the relays on models with the HT option.

Operation

The green LoopTracker[®] input LED provides a visual indication that a signal is being sensed by the input circuitry of the module. It also indicates the input signal strength by changing in intensity as the process changes from minimum to maximum.

If the LED fails to illuminate, or fails to change in intensity as the process changes, check the module power or signal input wiring. Note that it may be difficult to see the LEDs under bright lighting conditions.

The bi-color alarm LED provides a visual indication of the alarm status. In all configurations, a green LED indicates a non-alarm condition and a red LED indicates an alarm condition.

In the normal mode of operation, the relay coil is energized in a non-alarm condition and de-energized in an alarm condition. This will create an alarm condition if the module loses power. For a normal acting, non-latching configuration, the alarm will activate when the input signal exceeds the setpoint (HI alarm) or falls below the setpoint (LO alarm), then will automatically reset when the alarm condition no longer exists.


For a reverse acting alarm, the relay coil is de-energized in a non-alarm condition and energized in an alarm condition. The alarm activates when the input signal exceeds the setpoint (HI alarm) or falls below the setpoint (LO alarm), then automatically resets when the alarm condition no longer exists.

For models with the latching relay option, it will be necessary to push the Test button or remove power from the module to reset the alarm, depending on the type of latching option. The alarm will only reset if the alarm condition no longer exists.

API maintains a constant effort to upgrade and improve its prod-

Consult factory for your specific requirements.

Specifications are subject to change without notice



BSOLUTE **P**ROCESS **i**NSTRUMENTS, Inc.

ucts.

1220 American Way Libertyville, IL 60048 Phone: **800-942-0315** Fax: 800-949-7502

api-usa.com